


# **EAA** **SPORTPILOT** & LIGHT-SPORT AIRCRAFT™

MAY 2007  
WWW.EAA.ORG



**Skylark:  
The Doubly  
International LSA**

- **Weight & Balance for E-LSA**
- **The "McCullibird"**
- **User Fees: Two Views**



# Weight & Balance for E-LSA

WARNING YOU THROUGH THE PROBLEMS



By Michael "Mike" Huffman

In certificating light-sport aircraft (LSA) and conducting experimental LSA (E-LSA) repairman courses, I have found that completing a weight and balance (W&B) is confusing for many E-LSA owners. A completed W&B is required for the certification inspection, so this article lays out the basics of the subject in a way that will hopefully clear up the confusion.



We will discuss only fixed-wing E-LSA in this article. For weight-shift aircraft and powered parachutes (PPCs), the fore/aft location of the cart or trike center of gravity (CG) is much less critical than for fixed-wing aircraft. In recognition of that fact, the FAA has adopted the term “weight and loading” for trikes and PPCs.

### Two Kinds of Weight and Balance

Before we start talking technical, I want to clear up one item of confusion. I have noticed mechanics and pilots use the term weight and balance in different ways. To a mechanic (or the owner of an E-LSA preparing for a certification inspection), weight and balance means the act of actually weighing the aircraft to determine its empty weight and CG. It can also mean calculating a new empty weight and CG when equipment is added or removed. The mechanic or aircraft owner then produces a *weight and balance report* for the aircraft records.

To a pilot, weight and balance means starting with the empty weight and balance report and adding items of *useful load* (people, fuel, baggage, etc.) to determine whether the loaded weight and center of gravity are within the allowable limits before any given period of flight. That's an FAA requirement ... and of the laws of physics.

Part of this confusion arises because some ultralight manufacturers instruct owners to weigh the aircraft with a pilot in the seat and fuel in the tanks. In this article, we will discuss weight and balance from the mechanic's point of view, showing you how to create a conventional empty weight and balance report.

### Why Is W&B Important?

Knowing the weight of your airplane is important because a higher loaded weight causes:

- Greater forces applied to the wings in flight and during maneuvers.
- Greater forces applied to the landing gear and other parts of the aircraft during landing.
- Longer takeoff and landing distances.
- Slower climb rates.

Balance is important because loaded CGs aft of a certain point adversely affect:

- Longitudinal stability—the ability of the aircraft to return to its original flight path of its own accord,

without pilot intervention following a change in pitch attitude.

- Spin characteristics — when an aft-CG airplane spins, the spin is more likely to “go flat,” where the nose of the airplane rises and the controls become ineffective, thus making the spin unrecoverable.

Additionally, CG locations too far forward may affect the ability of the aircraft to rotate for takeoff or flare for landing.

Aircraft designers specify a maximum weight and CG range, determined through a combination of engineering calculations, load testing, and flight testing, within which the aircraft can be safely operated.

The FAA inspector or designated airworthiness representative (DAR) who inspects your aircraft for certification will require that you have physically weighed the aircraft, calculated the empty weight and center of gravity, calculated the most-forward and most-aft CG locations to be expected, and prepared an accurate weight and balance report.

### Some Basic Physics and Terminology

Before we get into the details, let's talk about leverage—a force applied at the end of a lever arm. Remember when you were a kid on the teeter-totter? As shown in the cartoon illustration, if your buddy on the other end weighed less than you, you would have to scoot further toward the pivot for the teeter-totter to balance. This is an example of leverage. Because you weigh more, your distance must be shorter.

The concept of a force multiplied by a distance is key to understanding and performing weight and balance. In aviation parlance, the distance is referred to as an *arm*, and the product of the weight times the arm is called a *moment*. Typically for small U.S.-registered airplanes, weights are expressed in pounds, arms in inches, and moments in inch-pounds.

So, if you were to set your aircraft on three scales—one for each wheel—you could read the weight on each wheel. Then, if you knew the arm measurement for each wheel, you could multiply the weight times the arm and get the moment for each wheel. If you added all three weights and all three moments, then divided the total moment by the total weight, the result would be the arm (better known as the CG location) for the airplane.

**The concept of a force multiplied by a distance is key to understanding and performing weight and balance.**







of the wing leading edge) makes the calculations easier. That is because arm measurements aft of the datum are considered positive (+) numbers and those forward of the datum are considered negative (-); by locating the datum well forward of the nose of the aircraft, all arms will be positive, thus eliminating the necessity to multiply, add, and subtract negative numbers.

Through a century of accumulated experience, it has been found that for conventional wing-forward/tail-aft airplanes, the most forward CG limit will generally be located at 20-25 percent of the wing chord and the most aft CG limit at 30-35 percent of the wing chord.

So, if your airplane had an acceptable CG range of 25 to 35 percent chord and your wing chord measured 60 inches, that would mean your acceptable CG range would be 15-21 inches aft of the wing leading edge. And, if the designer had chosen a datum 100 inches forward of the wing leading edge, the CG range would be 115-121 inches aft of the datum. Simple, huh?

If the airplane has a swept or tapered wing, the designer may reference the acceptable CG range to a *mean aerodynamic chord* (MAC), which is the mathematical equivalent to a constant-chord wing.

### Down to the Nitty-Gritty

Now, with that grounding, let's do a sample weight and balance. For this exercise, assume you own a Challenger II powered by a 52-hp Rotax 503. Figure 1 shows a side

AIRCRAFT WEIGHT & BALANCE REPORT - EQUIPMENT ADDITION/REMOVAL					
Date: 11/20/07					
Registration No.: N12345					
Manufacturer: QUAD CITY					
Model: CHALLENGER II					
Serial No.: CH000W000					
Performed by: JOHN J. SMITH <i>John J. Smith</i>					
				Determined From:	
				Manuf Data	My Data
Datum Location: 50" FRD OF MAIN WHEELS					
Leveling Means: "LEVEL FLIGHT ATTITUDE"					
Total Fuel Capacity: 10 GALLONS (80 LBS)					
Max Gross Weight: 800					
CG Range: 30-50" AFT OF DATUM					
Aircraft Empty					
	Item	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
Removed	Old aircraft empty	410	105.58	43214	
	BRS-3 ballistic parachute	-23	95	-1925	
	Added Garmin 155 GPS	2	24	48	
	New Empty Weight CG	389		41167	105.83
Most Air Loading					
	Item	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
	Aircraft empty	389	105.83	41167	
	Pilot	170	50	8500	
	Passenger	0	77	0	
	Baggage, NW	0		0	
	Fuel	45	155	5047	
	WeightCG	504		54714	89.99
Most Fuel Loading					
	Item	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
	Aircraft empty	389	105.83	41167	
	Pilot	170	50	8500	
	Passenger	170	77	13090	
	Baggage, NW	0		0	
	Fuel	26	123	2678	
	WeightCG	755		65435	86.67
Flight Test Loading					
	Item	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
	Aircraft empty	389	105.83	41167	
	Pilot	190	50	9500	
	Passenger	0	77	0	
	Baggage, NW	0		0	
	Fuel	60	123	7380	
	WeightCG	539		57927	85.04

FIGURE 4

view of the aircraft with all the manufacturer-supplied weight and balance specifications. (We are using the Quad City specified maximum weight of 800 pounds; in some cases it is now allowing an increase to 1,000 pounds.)

Before you actually weigh the airplane, you'll need to perform some preparatory steps:

- Clean the aircraft. Accumulated dirt and moisture have weight.
- Make certain there is no accumulated water or ice anywhere in the aircraft.
- Perform the weight and balance in a closed building with a flat, relatively level floor. Stray air currents may affect the scale readings.
- Assure that all items of required equipment are in the aircraft.
- Assure that no other items (headsets, knee boards) are in the aircraft.
- Drain the fuel tanks.
- Assure that, if installed, the oil reservoir and coolant system are full.
- If at all possible, use three scales. While it is feasible to use one scale and move it from wheel to wheel, the possibility of error is greater.
- Check the calibration of your scale. If you are using an uncalibrated scale (such as a bathroom scale), weigh a known-weight heavy object and a known-weight light object on each scale, noting the errors at both ends of the range. A convenient heavy object could be your own weight, if known accurately. A convenient light object might be a number of 1 gallon plastic jugs filled with water—8.33 pounds per gallon.


Begin your weight and balance report form. You may use one supplied by the manufacturer, one you made up, or one from another source. However, you should check ahead of time with your FAA office or DAR; they may have a specific form they want you to use. We created the one shown in Figure 2 as an Excel spreadsheet to simplify the calculations. As with any other piece of paper you generate for your aircraft records, be sure to list the date, the N number, the builder/model/serial number data, and your name and signature. The report form should also list datum location, leveling means, total fuel capacity, baggage allowance, maximum weight, and the allowable CG range. It is also a good idea to list where the information came from—that is, from the manufacturer or determined by the person performing the weight and balance.

Begin an equipment list report form, which is simply a list of all the equipment installed in the aircraft at the time of the weight and balance. After all, without an equipment list, how would you or the next owner know when equipment changes warranted a new weight and balance? Be sure to identify the equipment list in the same way as the weight and balance form. The equipment list we use is shown in Figure 3.

With that preparation, place the aircraft on the scales. Level the aircraft longitudinally and laterally using the *leveling means* specified by the manufacturer—in this case Quad City says only to place the Challenger II in a "level flight attitude." Although the Challenger II is a tricycle-gear airplane, with nobody in it, it rests on its



FIGURE 5



tail. Therefore, you'll need a scale under the tail, with some sort of stand to bring the nose wheel down level with the mains.

Don't set the brakes—that can introduce side forces that may affect scale readings; instead, use wheel chocks.

Make note of each scale reading, then take the aircraft off the scales. Next, weigh the wheel chocks or stands used on each scale (known as the *tare* weights)

and make note of the readings. Depending on how your weight and balance form is set up, you may need to subtract the tare weights before entering the data on the form. Our form allows entry of the total weight and the tare, and automatically calculates the net weight at each wheel, as shown in Figure 2.

Enter the arm for each scale location in the ARM column, then multiply the net scale weights times the arm and enter the result in the MOMENT column. Add all

EASY TO REGISTER TO TEST  
TEST 7 DAYS A WEEK  
IMMEDIATE RESULTS

**LaserGrade**<sup>®</sup>  
YOUR COMPUTER TESTING SPECIALIST

NEW BENEFIT TO EAA MEMBERS  
**SAVE \$5.00**  
ON YOUR NEXT FAA TEST  
AT ANY OF OUR  
TEST CENTERS

More pilots and mechanics choose  
LaserGrade to take their written FAA exams.

We have over 500 convenient testing  
centers ready to test you now!  
Give us a call today.

To find a LaserGrade testing center  
nearest to you, visit us on the Web at:  
[www.LaserGrade.com](http://www.LaserGrade.com)  
or call: 800-211-2754

The advertisement features a blue background with white stars and a faint grid pattern. The LaserGrade logo is prominent in the center, with a star above the 'e' in 'Grade'. The text is arranged in a clear, professional layout, highlighting the benefits of the testing service.



three net scale weights to get the total weight. Add all three moment figures to get the total moment. Then divide the total moment by the total weight to get the CG. (Note: Do not add the three individual figures in the ARM column.)

Now you have determined the aircraft empty weight and CG.

### CG Calculations

However, you also need to calculate the *most-aft* and *most-forward* loaded CG conditions and the loaded CG you plan to use during your Phase I flight testing.

The FAA *Aircraft Weight & Balance Handbook FAA-S-8083-1* describes the accepted method for calculating the most-aft and most-forward CG conditions. At the outset, we should acknowledge that, depending on the configuration of your airplane, using this method may not result in information that is particularly useful in planning a flight. However, we will explain it, since it is the accepted method. Here again, it would be a good idea for you to check with your FAA office or DAR beforehand; they may want you to use a different method.

The basic idea is to maximize or minimize useful load items whose arm locations fall outside the allowable CG limits. Thus, for the most-aft condition, you would maximize items that are located aft of the aft CG limit and minimize items forward of that limit. For the most-forward CG calculation, you would maximize items forward of the forward CG limit and minimize items aft

AIRCRAFT WEIGHT & BALANCE REPORT- ACTUAL WEIGHT					
Date:	10/10/2008				
Registration No:	N555RC				
Manufacturer:	RANS INC				
Model:	S-4ES				
Serial No.:	8205399				
Performed By:	G. MICHAEL HUFFMAN <i>G. Michael Huffman</i>				
				Determined From:	
Datum Location:				Manuf Data	My Data
Leveling Means:				X	X
Total Fuel Capacity:				X	X
Max Gross Weight:				X	X
CG Range:				X	X
CG Range:				62.5" - 73" AFT OF DATUM	
Empty Weight & CG	Weighing Point	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
Left main wheel	Scale reading	338			
	Tare	2			
	Net weight	336	55.5	18648	
Right main wheel	Scale reading	340			
	Tare	3			
	Net weight	337	55.5	18703.5	
Tailwheel or nosewheel	Scale reading	24			
	Tare				
	Net weight	24	326	9424	
Empty weight/CG:		697		42775.5	61.37
Most Aft Loading	Item	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
	Aircraft empty	697	61.37	42775.5	
	Pilot	170	72	12240	
	Passenger	170	72	12240	
	Baggage	50	90	4500	
	Fuel	108	72	7776	
Weights/CG:		1195		79531.5	66.55
Most Fuel Loading	Item	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
	Aircraft empty	697	61.37	42775.5	
	Pilot	170	72	12240	
	Passenger	0	72	0	
	Baggage	0	90	0	
	Fuel	40	72	2880	
Weights/CG:		907		57895.5	63.83
Flight Test Loading	Item	Weight (lbs)	Arm (in)	Moment (in-lbs)	Center of Gravity (in)
	Aircraft empty	697	61.37	42775.5	
	Pilot	185	72	13320	
	Passenger	0	72	0	
	Baggage	0	90	0	
	Fuel	108	72	7776	
Weights/CG:		990		63871.5	64.52

FIGURE 6



The Flight Design CT is a leader in LSA performance. Now we can get you flying even faster with immediate delivery available at many of our dealers. Flight Design delivered more Light Sport Aircraft in 2006 than any other company and has increased production again for 2007. No waiting and dreaming: go flying now!


With all its standard features and popular options, no wonder CT is outselling most other brands combined. All CTs offer: 100 hp Rotax 912S, BRS 1350HS parachute system, carbon fiber cantilevered airframe for low drag and amazing structural strength, awesome visibility, giant 49 inch wide cabin with large easy-to-enter doors, two-way adjustable seats, two convenient baggage compartments, three-blade Neuform composite propeller, LED position and strobe lights, ELT...features many other brands call options.

Flight Design is also building a professional Dealer and Service Center network to keep you in the air where you belong! Find a CT dealer at the Flight Design USA website (go to flightdesignusa.com and click on dealers). If you check out the CT closely, you will be impressed by its combination of performance, payload, comfort and range. Go find out for yourself just how fast you can fly in a Flight Design CT!



CLASSIC PANEL

ADVANCED PANEL



## FLIGHT DESIGN USA

P.O. Box 325 S. Woodstock, Connecticut 06267

860.963.7272 flightdesignusa@rcn.com

www.flightdesignusa.com






## Know the ROTAX



### ROTAX 912 Engine Introduction Basic Operation and Maintenance for Pilots and Mechanics

The newest DVD from ASA's Freedom to Fly video series provides tips and techniques for trouble-free operation of a Light-Sport Aircraft (LSA) with a ROTAX engine and provides an introduction to the specific concepts important in maintaining the 912. Includes typical procedures every owner, operator, and mechanic should know to prolong engine life and reduce maintenance costs.

For more information visit [www.asa2fly.com](http://www.asa2fly.com) and search ROTAX.



ROTAX 912 Engine Introduction (ASA-F2F-ROTAX) \$49.95



AVIATION SUPPLIES & ACADEMICS, INC. | Since 1947  
Quality & Service You Can Depend On

See our complete line of study aids, textbooks, pilot supplies and more at your local airport and in bookstores nationwide. Pick up what you need TODAY!

Look for the ASA logo

Call 1.800.ASA.2.FLY for the dealer nearest you or check us out online at [www.asa2fly.com](http://www.asa2fly.com)

of that limit. For both conditions, you must assure that the resulting loaded weights and CGs are within the aircraft maximum weight and CG range.

Note that using the official FAA handbook method, if the useful load items are all within the allowable CG range (as would be the case for, say, a RANS S-6 Coyote), your most-aft and most-forward loading conditions may well be the same.

According to the FAA handbook, the pilot/passenger weight to be used for most-aft and most-forward calculations is 170 pounds, rather than the actual anticipated weight of the occupants.

Also, minimum fuel weight should be calculated using the FAA handbook formula: 1/12 gallon per maximum-except-take-off (METO) engine horsepower. Since gasoline weighs 6 pounds per gallon, an easy way to figure minimum fuel weight is to simply divide the engine horsepower by two. For example, the minimum fuel weight for 52-hp Rotax 503 would be 26 pounds or about 4.7 gallons. With some ultralights, this may seem like a lot of fuel, but it is the FAA-accepted way of calculating minimum fuel.

For our Challenger II, Figure 2 shows that the most aft CG worked out to include the pilot (which we always include) and no passenger. As instructed, we used the standard weight of 170 pounds for the pilot. Also, to keep the most-aft CG within the 80- to 90-inch range specified by the manufacturer, we can carry only 49 pounds of fuel, short of the 60-pound capacity.

The most-forward condition worked out to include only the pilot, a passenger, and the 26-pound minimum fuel as calculated using the standard formula explained above.

Last but not least, your FAA inspector/DAR may want to see the actual loading you plan to use for your Phase I flight test. Here, as shown in Figure 2, we use the actual pilot weight rather than the FAA-standard 170-pound figure, along with the actual fuel loading we plan to use. Your operating limitations document requires that the pilot be the only occupant of the aircraft during Phase I flight



testing, so no passenger weight is included.

You now have completed the weight and balance report and CG locations.

#### **Adding or Removing Equipment**

What happens if you add or remove equipment? Do you have to re-weigh the aircraft? The answer: If you know the accurate weight and arm of any piece of equipment added or removed, you can use the last weight and balance report to calculate a new weight and balance, without re-weighing the aircraft. Figure 4 shows a hypothetical example for our Challenger II, where we removed the ballistic parachute and added a GPS receiver.

We start by entering the old aircraft empty weight/CG information and then listing each item of equipment added or removed. The weight for any item added will be listed as a positive number; the weight of any item removed will be negative. If we are using a datum located forward of the aircraft, all arm measurements will be positive numbers. Recalling high school algebra, if we multiply a negative number by a positive number, the result will be negative.

After calculating the new empty weight and CG, we need to recalculate the most-aft, most-forward, and flight-test loadings and enter them on the form. This report then becomes the current weight and balance report for the aircraft records. It is a good idea to keep the old report, but mark it as "Superseded by new weight and balance dated xx/xx/xx."

Finally, where should you keep your weight and balance report? In reality, there is no specific FAA regulation that requires you to carry it in the airplane on every flight. However, EAA recommends that you carry it in the aircraft, first making certain it is current and accurate. Without it, an FAA ramp check inspector might argue that you had violated CFR 91.13 (careless or reckless operation) or 91.103 (preflight familiarization).

Questions or comments? Contact Mike Huffman at [sportaviation@kc.rr.com](mailto:sportaviation@kc.rr.com), or EAA's Aviation Services staff at 888-322-4636 or e-mail [info@eaa.org](mailto:info@eaa.org).

**For conventional wing-forward/tail-aft airplanes, the most forward CG limit will generally be located at 20-25 percent of the wing chord and the most aft CG limit at 30-35 percent.**

# TOXO

Toxo SLSA | Just feel it

## Touch down!

Toxo Sportster SLSA  
The Standard of Excellence



**CAG**  
COMPOSITE AEROGROUP

[www.toxo.aero](http://www.toxo.aero)  
[www.compositeaerogroup.com](http://www.compositeaerogroup.com)  
1-800-917-6648

*See us at EAA  
Adventure at Oshkosh*

Our Oshkosh booth number  
is Combo M